






P68.30-2584-09

- |                    |                        |                   |
|--------------------|------------------------|-------------------|
| 1 Nuts             | 5 Rear shelf           | 8 Electrical line |
| 2 Covers           | 6 Electrical connector | 9 Nut             |
| 3 Locking controls | 7 Roller blind         | 10 Guides         |
| 4 Spreading clip   |                        |                   |

**Modification notes**

22.1.04	Disconnect/connect/remove ground lead from battery		
---------	--	--	--

	Remove/Install		
1	Unscrew nuts (1)		
2	Unclip covers (2)		
3	Release rear seat backrest and fold forward	 See Operating Instructions	
4	Unhook locking controls (3) in trunk from the rear seat backrest lock.		
5	Remove paneling on C-pillar		AR68.30-P-4490Q
6	Remove rubber buffer		
7	Remove spreading clips		
8	Lift rear shelf (5) until electrical connector (6) is accessible		
9	Unplug electrical connector (6)		
10	Take out rear shelf (5) with roller blind (7)		
11.1	Loosen electric lead (8) from rear shelf (5)	Only when replacing rear shelf (5)  <b>Installation:</b> Fasten electric lead (8) to rear shelf (5) with strips of adhesive tape.	
12.1	Slacken nuts (9)	Only when replacing rear shelf (5)  <b>Installation:</b> Carefully screw on nut (9) by hand to prevent damaging rear shelf (5)	
13.1	Remove roller blind (7)	Only when replacing rear shelf (5)  <b>Installation:</b> Slide roller blind (7) up to stop into guides (10)	
14	Install in the reverse sequence		