



Wedge

- 1  Insert wedge into timing case cover between tensioning rail (2) and slide rail.
- 2  Press wedge down all the way and in this way detension the timing chain (1).



P05.10-2151-11