



P82.62-3267-09

Shown with code (809) Model year 2009

- |   |                  |   |                      |         |                     |
|---|------------------|---|----------------------|---------|---------------------|
| 1 | Floor covering   | 4 | Nuts                 | H4/29   | Subwoofer           |
| 2 | Damping material | 5 | Electrical connector | H4/29x1 | Subwoofer connector |
| 3 | Footrest         |   |                      |         |                     |

Remove/install		
1	Fold back floor covering (1) in front passenger footwell	
2	Remove soundproofing (2) from front passenger footwell	
3	Remove footrest (3)	
4	Unscrew nuts (4)	
5	Disconnect electrical connector (5) and subwoofer speaker connector (H4/29x1)	<b>i</b> Unlock electrical connector (5) before disconnecting (arrow).
6	Remove subwoofer speaker (H4/29) from front passenger footwell	
7	Install in the reverse order	