


MODELS 203, 209 with CODE (580a) Automatic air conditioning

MODELS 203, 209 with CODE (581b) Convenience automatic air conditioning



P83.30-3400-09

B10/6 Evaporator temperature sensor

☒ ☒	Remove/Install		
1	Remove cover below instrument panel (left)		AR68.10-P-1500P
2	Pull evaporator temperature sensor (B10/6) out of the evaporator housing in direction of arrow		
3	Disconnect connector from evaporator temperature sensor (B10/6)		
4	Install in the reverse order		