

Document number:


pe82.62-p-2101-97fa

Document title:


Wiring diagram of sound amplifier control module

Position:**Code:****Designation:**

A0	Color code key	
A2/13	Sound amplifier	
A2/13	Sound amplifier	
A2/13	Sound amplifier	
B25/6	Sound amplifier microphone	
B25/6x1	Sound amplifier microphone connector	
F34	Interior fuse box	
F34f26	Fuse 26	
H4/1	Left front door speaker	
H4/2	Right front door speaker	
H4/23	Left front door mirror triangle speaker	
H4/24	Right front door mirror triangle speaker	
H4/27	Center cockpit speaker (centerfill)	
H4/29	Subwoofer	
H4/29	Subwoofer	
H4/5	Left rear door speaker	
H4/6	Right rear door speaker	
U57	Valid for model 203.2	
U58	Valid for model 203.0	
W6	Ground (left wheelhouse in luggage compartment)	
W7	Ground (right wheelhouse in luggage compartment)	
X18/35	Cockpit wiring harness and FFS [RBA] connector	
X35/1	Left front door separation point	
X35/2	Right front door separation point	
X35/3	Left rear door separation point	
X35/4	Right rear door separation point	
X38	Speaker intermediate connector	
X58/3	Microphone separation point	
Z20/26	Cable end insulation not stripped, placed inside insulated tubing	



Affix page 2 here ▼



Cut here