




P77.39-2104-09

1 Connector

2 Soft top compartment cover hydraulic cylinder

S84/13 Soft top compartment cover "open/closed" switch group

	Remove/Install		
1	Open trunk lid		
2	Remove paneling in trunk	 Remove only left side wall paneling.	AR68.30-P-4600QA
3	Separate connector (1)	 Shown on vehicle with open soft top compartment cover.	
4	Unclip soft top compartment cover open/closed switch group (S84/13) from soft top compartment cover hydraulic cylinder (2).		
5	Install in reverse order		