

P77.39-2163-09

Shown on model 209.4

1 Cover


2 Expansion clip

3 Electrical connector

4 Screw

S84/22

Soft top compartment cover in catch position limit switch

	Remove/install		
⚠ Danger!	Risk of injury when performing check and repair work in area of roll bar	Before working in the area of the roll bar, pull out the rear head restraints by hand. Keep body parts out of the area where the roll bar extends.	AS91.00-Z-0003-01QA
⚠ Danger!	Risk of injury caused by moving parts that can pinch, crush or, in extreme cases, even sever extremities	No parts of the body or limbs should be within the operating range of the mechanism when moving components.	AS00.00-Z-0009-01A
⚠ Danger!	Risk of injury caused by scraping or cutting body parts on sharp vehicle parts	Always wear protective gloves when working on or near sharp and non-deburred vehicle parts. Deburr repair panels.	AS00.00-Z-0017-01A
1	OPEN soft top	i Leave soft top compartment lid positioned upright	
2	Cover vehicle in left and right rear area	⚠ To prevent scratching the paint during assembly work.	
3	Remove expansion clips (2)	i On model 207.4 only four expansion clips (2) are installed.	
4	Remove cover (1) upward	i Installation: Ensure correct seating of the cover (1).	
5	Unscrew left and right bolt (4)		
6	Unclip soft top compartment lid limit switch in catch position (S84/22)	i Installation: Observe installation position of soft top compartment lid limit switch in catch position (S84/22).	
7	Disconnect electrical connector (3)		
8	Install in the reverse order		