

P80.57-2020-07





1 Rosette
2 Electrical connectors

3 Bowden cable

N73 EIS [EZS] control unit

Modification notes

21.11.05	Disconnect ground line replaced by switching on ignition	Step 1	
----------	--	--------	--

	Remove/install		
	Information on preventing damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1	Switch off ignition and remove transmitter key from EIS control unit	 On vehicles with code (889) Keyless Go, press the Keyless Go start/stop button repeatedly until the ignition is switched off. Remove Keyless Go transmitter card or transmitter key from vehicle and store beyond reach of transmitter (min. 2 m).	
2	Remove instrument panel bottom on driver side	 Do not remove rotary light switch	AR68.10-P-1505R
3	Disconnect electrical connectors (2) from EIS control unit (N73)		
4	Unclip control cable (3) from EIS control unit (N73) and remove EIS control cable (N73)		
5	Install in opposite order		