
GF54.15-P-1257-02RI	Relay assignment of fuse and relay box in	⊯ GF
	right engine compartment	

K40/4 Passenger-side fuse and relay module

X Direction of travel



P54.15-2317-05

Relay	Designation
K	 Engine electronics and chassis relay (K40/4kK)
L	Starter relay (K40/4kL)
М	Valid for engines 272, 273, 275: ■ Circuit 30z relay (K40/4kM)
N	-
0	Valid for engines 272, 273, 275: • Air pump or reserve relay (K40/4kO)
Р	Fanfare horn relay (K40/4kP)