

- Instrument cluster paneling 1 2 Bolts
- З
- Electrical connector 4 Instrument panel

P54.30-9406-07

Modification notes

21.11.05	Disconnect ground line replaced by switch off ignition	Step 3	

A1

Instrument cluster

XX	Remove/install		
())	Information on preventing damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1.1	Buffer basic data from instrument cluster (A1) in STAR DIAGNOSIS	When installing new instrument cluster (A1).	
		<b>i</b> Installation: Transfer the cached basic data to the new instrument cluster (A1).	
li≉ A D	Connect STAR DIAGNOSIS and read out fault memory		AD00.00-P-2000-04A
		STAR DIAGNOSIS diagnosis system	*WH58.30-Z-1048-13A
2	Remove trim of instrument cluster (1)		AR68.10-P-3511R
3	Switch off the ignition and remove the transmitter key from the EIS control unit	Don vehicles with code (889) Keyless Go, press the Keyless Go start/stop button repeatedly until the ignition is switched off. Remove the Keyless Go transmitter card or transmitter key from the vehicle and store beyond the reach of the transmitter (min. 2 m).	
4	Remove bolts (2) from instrument cluster (A1)		
5	Pull instrument cluster (A1) out of the instrument panel (4) until the electrical connector (3) is accessible		
6	Release and unplug electrical connector (3) and remove instrument cluster (A1).		
7	Install in the reverse order		
8.1	Read fault memory, erase if necessary	Only if the instrument cluster (A1) has not been replaced.	
₩ A D	Connect STAR DIAGNOSIS and read out fault memory		AD00.00-P-2000-04A
		STAR DIAGNOSIS diagnosis system	*WH58.30-Z-1048-13A

## Commercially available tools

Number	Designation	
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car	6511 1801 00