
Assignment of fuse and relay box in rear

in rear

1-20 Fuses A-H Relays

N10/2 Rear SAM control module with

fuse and relay module



P54.15-2206-06

Bay	Designation
Α	Fuel pump relay (N10/2kA)
В	Relay 2, terminal 15R (N10/2kB)
С	Reserve relay 2 (N10/2kC)
D	Reserve relay 1 (N10/2kD)
E	Rear window defroster relay (N10/2kE)
F	Relay 1, terminal 15R (N10/2kF)
G	Filler cap relay, polarity reverser 1 (N10/2kG)
Н	Filler cap relay, polarity reverser 2 (N10/2kH)