



P72.10-2523-09

1 Door liner

2 Plastic head

3 Loudspeaker cover

	Remove		
1	Remove door liner at front door (1)	⚠ Put down door liner (1) on a suitable base to avoid damage.	AR72.10-P-1000Q
2	Separate plastic head (2)		
3	Remove speaker cover (3)		
	Install		
4	Insert speaker cover (3)		
5	Press clamping plates over the pins of the speaker cover (3)		
6	Shorten pins of speaker cover (3)		