

- Parts list -

Mode : MD mode Mod. des. overview : CLK COUPE
 FIN/MD : 209375 Catalog : 69M
 VIN : Major assembly :
 Sales designation : CLK 500 Major assembly MD :
 Assortment class : Car Group : 83 - HEATING AND VENTILATION
 Market : All Subgroup : 035 - HEATER AND EVAPORATOR HOUSING WITH BLOWER AND WIRING HARNESS

Item no.	Part number	Designation/description	Quantity	Version
10	A 209 830 01 62	EVAPORATOR HOUSING Code: 580	001	L
10	A 209 830 00 62	EVAPORATOR HOUSING Code: 580	001	R
10	A 209 830 03 62	EVAPORATOR HOUSING Code: 581	001	L
10	A 209 830 02 62	EVAPORATOR HOUSING Code: 581	001	R
20	A 203 830 01 03	. HOUSING AIR DISTRIBUTOR <input type="checkbox"/> [409] TO BE ADAPTED DURING ASSEMBLY	001	L
20	A 203 830 23 03	. HOUSING TOP SECTION AIR DISTRIBUTOR Code: 581 <input type="checkbox"/> [409] TO BE ADAPTED DURING ASSEMBLY	001	L
20	A 203 830 24 03	. HOUSING AIR DISTRIBUTOR <input type="checkbox"/> [409] TO BE ADAPTED DURING ASSEMBLY	001	R
30	A 203 830 01 40	. OPERATING LEVER LEFT	001	
40	A 203 830 02 40	. OPERATING LEVER RIGHT	001	
50	A 203 830 15 03	. AIR DUCT LEGROOM,LEFT	001	
60	A 203 830 16 03	. AIR DUCT LEGROOM,RIGHT Code: 580	001	
60	A 203 830 18 03	. AIR DUCT LEGROOM,RIGHT Code: 581	001	
70	A 203 835 06 98	. SEAL CONDENSED WATER DRAIN	001	
80	A 220 830 07 72	. TEMPERATURE SENSOR EVAPORATOR	001	
90	A 203 820 16 42	. STEPPER MOTOR SERVOMOTOR Code: 580	006	
90	A 203 820 16 42	. STEPPER MOTOR SERVOMOTOR Code: 581	010	
100	A 203 830 05 03	. HOUSING BLOWER SIDE Code: 580	001	L
100	A 203 830 06 03	. HOUSING BLOWER SIDE Code: 580	001	R
100	A 203 830 07 03	. HOUSING BLOWER SIDE Code: 581	001	L
100	A 203 830 08 03	. HOUSING BLOWER SIDE Code: 581	001	R
110	A 203 820 25 14	. ELECTRIC MOTOR	001	L
110	A 203 820 26 14	. ELECTRIC MOTOR	001	R

120	A 230 821 02 51	. BLOWER REGULATOR Replaced by: A 230 821 63 51	001	
120	A 230 821 63 51	. BLOWER REGULATOR	001	
130	A 203 830 26 03	. HOUSING FRESH AIR/CIRCULATING AIR	001	L
130	A 203 830 14 03	. HOUSING FRESH AIR/CIRCULATING AIR Code: 581	001	L
130	A 203 830 19 03	. HOUSING FRESH AIR/CIRCULATING AIR Code: 581	001	R
130	A 203 830 28 03	. HOUSING Code: 580	001	R
140	A 203 830 05 18	. FILTER AKTIVKOHLEFILTER Replaced by: A 203 830 21 18 Code: 581	001	
140	A 203 830 21 18	. ACTIVATED CHARCOAL FILTER Code: 581	001	
150	A 203 830 12 03	. HOUSING LID ACTIVATED CHARCOAL FILTER Code: 581	001	
160	A 203 997 00 25	. EXPANSION PLUG	001	
170	A 203 835 00 93	. SOUNDPROOFING BLOWER HOUSING ON FIREWALL	002	
180	A 203 830 00 32	. LINKAGE FOOTWELL FLAPS WITHOUT OPERATING LEVER	001	
185	A 203 830 00 33	. OPERATING LEVER LEGROOM,LEFT AND RIGHT	001	
190	A 203 835 01 11	. PLATE	001	R
200	A 203 830 01 61	. HEAT EXCHANGER	001	
210	A 203 830 16 15	. PIPELINE HEAT EXCHANGER	001	L
210	A 203 830 17 15	. PIPELINE HEAT EXCHANGER	001	R
220	A 000 835 37 98	. ROUND SECTION SEAL RING PIPE TO HEAT EXCHANGER	002	
230	A 203 835 00 14	. BRACKET HEAT EXCHANGER	001	
240	A 203 835 00 11	. PLATE PIPE LINE FIXTURE	001	L
250	A 203 835 03 98	. SEAL FIRE WALL	001	L
250	A 203 835 05 98	. SEAL FIRE WALL	001	R
260	A 209 830 01 58	. EVAPORATOR	001	L
260	A 209 830 02 58	. EVAPORATOR Replaced by: A 209 830 05 58	001	R
260	A 209 830 05 58	. EVAPORATOR	001	R
260	A 209 830 03 58	. EVAPORATOR Code: 494	001	L
270	A 140 997 09 45	. O-RING SUCTION LINE TO EXPANSION VALVE 17X2	001	
280	A 140 997 07 45	. O-RING PRESSURE LINE TO EXPANSION VALVE 10.6X2	001	
290	A 230 830 01 84	. VALVE EXPANSION VALVE	001	
300	A 203 830 12 15	. WIRING HARNESS SERVOMOTOR Code: 580	001	L
300	A 203 830 14 15	. WIRING HARNESS SERVOMOTOR Code: 580	001	R
300	A 203 830 13 15	. WIRING HARNESS SERVOMOTOR Code: 581	001	L
300	A 203 830 15 15	. WIRING HARNESS SERVOMOTOR Code: 581	001	R
310	A 001 984 58 29	. BOLT M4X16	035	

[002] To Chassis: F 123374 To Date: 01/08/2004

310	A 001 984 58 29	. BOLT M4X16 Code: 580 [003] From Chassis: F 088109 From Date: 14/01/2004	035	
310	A 001 984 58 29	. BOLT M4X16 Code: 581	045	
320	A 000 835 31 34	. SPRING	043	
330	A 006 997 33 48	. SEAL RING 17.1 X 2.6 MM	001	
340	N 910104 006000	NUT-AND-WASHER ASSEMBLY MOUNTING HEATER TO CROSSMEMBER M6 Replaced by: N 000000 004471	003	
340	N 000000 004471	NUT-AND-WASHER ASSEMBLY MOUNTING HEATER TO CROSSMEMBER Replaced by: N 910104 006001	003	
340	N 910104 006001	NUT-AND-WASHER ASSEMBLY MOUNTING HEATER TO CROSSMEMBER M6	003	
390	A 211 830 05 72	SENSOR DEW POINT SENSOR Code: 580 [004] To Chassis: F 209988 To Date: 02/07/2006	001	
390	A 203 837 01 10	COVER DEW POINT SENSOR Code: 580 [005] From Chassis: F 209989 From Date: 02/07/2006	001	
390	A 211 830 05 72	SENSOR DEW POINT SENSOR Code: 580+919 [006] To Chassis: F 155085 To Date: 28/02/2005	001	
390	A 203 837 01 10	COVER DEW POINT SENSOR Code: 580+919 [007] From Chassis: F 155086 From Date: 28/02/2005	001	
456	A 000 546 11 45	INSULATING SLEEVE BLOWER MOTOR, REAR FF6.3;M2/1 Code: 581	001	
500	A 203 830 00 08	BLOWER MOTOR IN HOUSING CENTER CONSOLE Code: 581/589	001	
509	A 220 545 39 28	PLUG HOUSING RECIRCULATED AIR UNIT 4-PIN SLK2.8;A32	001	
510	A 220 820 92 10	BLOWER REGULATOR Code: 581/589	001	
520	A 203 830 13 13	COVER TOP Code: 581/589 [008] To Chassis: F 070725 To Date: 30/06/2003	001	
520	A 203 830 01 52	COVER TOP Code: 589 [009] From Chassis: F 070726 From Date: 30/06/2003	001	
530	A 203 835 01 19	COVER AT BLOWER Code: 589	001	
550	A 203 835 01 98	SEAL AIR INTAKE Replaced by: A 203 835 14 98	001	
550	A 203 835 14 98	SEAL AIR INTAKE	001	
555	A 004 988 36 78	CLIP SEAL	002	
560	A 203 832 13 94	HOSE CONDENSED WATER DRAIN	002	
564	A 032 545 19 28	PLUG HOUSING EVAPORATOR TEMPERATURE SENSOR 2-PIN MQS;B10/6	001	
570	A 203 835 00 32	INTERMEDIATE PIECE CRUISE CONTROL CRASH ABSORBER Code: 494	001	L
840	A 000 546 83 40	SOCKET 0.5-1.0 MM2 FF6.3	NB	
899	A 016 545 41 26	FEMALE CONTACT 0.25-0.5 MM2 MQS	NB	

956	A 013 545 14 26	CONTACT SPRING 0.22-0.5 MM2 SLK2.8	NB
956	A 013 545 15 26	CONTACT SPRING 0.75-1.0 MM2 SLK2.8	NB
956	A 011 545 07 26	CONTACT SPRING 4.0 MM2 SLK2.8	NB