



P83.10-2357-09

- 1 Bolts
- 2 Vapor barrier
- 3 Electrical connector
- M2/10 Left footwell flap positioning motor

Modification notes

18.2.04	Disconnect/connect/remove ground lead from battery		
---------	--	--	--

		Removal/installation	
		1 Remove cross member under instrument panel	AR68.10-P-1120QA
		2 Remove damping (2)	
		3 Remove bolts (1)	
		4 Detach left footwell flap actuator motor (M2/10)	
		5 Separate electrical connection (3)	
		6 Install in the reverse order	
		7 Connect STAR DIAGNOSIS, normalize left footwell flap actuator motor (M2/10), read out and erase fault memory	AD00.00-P-2000-04A
	AD	Connect STAR DIAGNOSIS and read out fault memory	*WH58.30-Z-1048-13A
		8 Perform function check	Diagnosis system STAR DIAGNOSIS

Commercially available tools

Number	Designation	
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car	6511 1801 00