
AR67.30-P-4200-02Q	Adjust window transition of rear side window	

Test values for rear side window

Number	Designation			Model 209.3
BE67.30-P-1001-01E	Transition between door window and rear side window	Dimension "a"	mm	1




1 Check dimension "a" between door window (1) and rear side window stay (2)



P67.30-2102-06

- 2 Adjustment by means of adjustment screw (1) with socket wrench
- i If transition cannot be created: Adjust driver's door with upper power window mounting point by opening behind SRS badge with socket wrench.



P67.30-2097-01