


## MODEL 209




- 1 Bolts  
 2 Coupling connection to blower regulator (A32n1)  
 A32m1 Blower motor  
 A32n1 Blower regulator



P83.25-2087-05

## Modification notes

16.5.06	"Disconnect/connect ground line on battery" removed		
---------	---	--	--

 	Remove/install		
1	Remove glove compartment		AR68.10-P-1400Q
2	Remove cover below instrument panel		
3	Remove bolts (1)		
4	Disconnect connector from blower regulator (A32n1)		
5	Expose lead at blower motor (A32m1)		
6	Remove blower motor (A32m1) with blower control unit (A32n1)	 Do not lay blower motor (A32m1) on the fan wheel.	
7	Install in the reverse order		