




- Parts list -

Mode :	MD mode	Mod. des. overview :	CLK CONVERTIBLE
FIN/MD :	209475	Catalog :	69W
VIN :		Major assembly :	
Sales designation :	CLK 500	Major assembly MD :	
Assortment class :	Car	Group :	33 - FRONT AXLE
Market :	All	Subgroup :	030 - STEERING KNUCKLE AND CONTROL ARM

Item no.	Part number	Designation/description	Quantity	Version
10	A 209 332 00 01	STEERING KNUCKLE FRONT LEFT Replaced by: A 204 332 01 01	001	
10	A 204 332 01 01	STEERING KNUCKLE FRONT LEFT Code: -P98	001	
10	A 209 332 01 01	STEERING KNUCKLE FRONT RIGHT Replaced by: A 204 332 02 01	001	
10	A 204 332 02 01	STEERING KNUCKLE FRONT RIGHT Code: -P98	001	
20	A 209 330 03 25	FRONT WHEEL HUB WITH BEARING Code: -P98	002	
30	A 203 330 00 51	ANTI-FRICTION BEARING REPAIR KIT Code: -P98	002	
35	A 203 330 00 60	SEAL RING FRONT WHEEL HUB, INSIDE Code: -P98	002	
40	A 116 334 03 72	NUT FRONT WHEEL HUB TO STEERING KNUCKLE Code: -P98	002	
45	N 000000 003358	HEXALOBULAR BOLT FRONT WHEEL HUB TO STEERING KNUCKLE M6X25 Code: -P98	002	
50	A 168 357 00 89	PLUG FRONT WHEEL HUB, OUTER Code: -P98	002	
90	A 203 330 35 11	STRUT FRONT LEFT Replaced by: A 203 330 39 11 Code: -P98 <input type="checkbox"/> [408] ONLY REPLACEABLE BY PAIRS	001	
90	A 204 330 33 11	STRUT FRONT LEFT Replaced by: A 204 330 43 11 Code: -P98 <input type="checkbox"/> [408] ONLY REPLACEABLE BY PAIRS	001	
90	A 203 330 39 11	STRUT LEFT WITHOUT BEARING Replaced by: A 204 330 33 11 Code: -P98	001	
90	A 204 330 43 11	STRUT LEFT WITHOUT BEARING Code: -P98	001	
90	A 203 330 36 11	STRUT FRONT RIGHT Replaced by: A 203 330 40 11 <input type="checkbox"/> [408] ONLY REPLACEABLE BY PAIRS	001	

90	A 204 330 34 11	STRUT FRONT RIGHT  [408] ONLY REPLACEABLE BY PAIRS	001
90	A 203 330 40 11	STRUT RIGHT WITHOUT BEARING Replaced by: A 204 330 44 11	001
90	A 204 330 44 11	STRUT RIGHT WITHOUT BEARING	001
100	A 203 333 10 14	RUBBER BUSHING LEFT AND RIGHT  [002, 003] OBSERVE WIS	001
100	A 203 333 10 14	RUBBER BUSHING LEFT AND RIGHT  [003] ALSO USE: 2 X A 211 333 06 97 BOOT, OBSERVE WIS	001
110	N 000000 003281	HEXAGON NUT STRUT TO STEERING KNUCKLE	002
120	A 220 333 00 71	BOLT TORQUE STRUT TO FRAME-TYPE INT. SUPP. M14X1.5	002
130	A 220 333 00 76	SHIM TORQUE STRUT TO FRAME-TYPE INT. SUPP.	004
140	N 000000 003281	HEXAGON NUT TORQUE STRUT TO FRAME-TYPE INT. SUPP.	002
150	A 000 330 00 18	TS BOLT PARTS KIT FOR ADJUSTING WORK ONLY	002
160	A 203 330 33 11	CROSS STRUT FRONT LEFT	001
160	A 204 330 19 11	CROSS STRUT FRONT LEFT Code: -P98	001
160	A 203 330 34 11	CROSS STRUT FRONT RIGHT Replaced by: A 204 330 20 11 Code: -P98	001
160	A 204 330 20 11	CROSS STRUT FRONT RIGHT Code: -P98	001
165	A 203 333 09 14	. BEARING THRUST ARM	002
180	N 000000 003281	HEXAGON NUT CROSS STRUT TO STEERING KNUCKLE, LEFT AND RIGHT	002
190	A 220 333 00 71	BOLT CROSS STRUT TO INTEGRAL CARRIER M14X1.5	002
200	A 220 333 00 76	SHIM CROSS STRUT TO INTEGRAL CARRIER	004
210	N 000000 003281	HEXAGON NUT CROSS STRUT TO FRAME-TYPE INTEGRAL SUPPORT, LEFT AND RIGHT	002
220	A 000 330 00 18	TS BOLT PARTS KIT FOR ADJUSTING WORK ONLY	002