



P83.10-2266-09

- 1 Bolts
- 2 Cross member below instrument panel
- 3 Electrical connector
- M2/10 Left footwell flap positioning motor

**Modification notes**

18.2.04	Disconnect/connect/remove ground lead from battery		
---------	--	--	--

🔍	Remove/Install		
1	Remove cross member under instrument panel (2)		AR68.10-P-1120Q
2	Remove damping in the area of the left footwell flap actuator motor (M2/10)		
3	Remove bolts (1)		
4	Detach left footwell flap actuator motor (M2/10)		
5	Separate electrical connection (3)		
6	Install in the reverse order		
7	Connect STAR DIAGNOSIS, normalize left footwell flap actuator motor (M2/10), read out and erase fault memory Connect STAR DIAGNOSIS and read out fault memory	Diagnosis system STAR DIAGNOSIS	AD00.00-P-2000-04A *WH58.30-Z-1048-13A
8	Perform function check		

**Commercially available tools**

Number	Designation	
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car	6511 1801 00