

VIN	WDB2211761A123456	Model series/model designation	230.479
Order number		License plate	

Full list of fault codes and events

4001	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
412E	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
412F	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4130	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4132	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4134	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4136	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4141	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4142	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4143	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4150	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4151	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4152	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4160	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4161	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4170	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4175	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4190	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41B0	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41B8	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41B9	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41BA	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41BB	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41BC	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41BD	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41BE	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41BF	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41C0	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41C1	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41C2	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41C3	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D0	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D1	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D2	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D3	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D4	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D5	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D6	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41D7	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41DA	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41DB	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.

41DC Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41DD Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41DE Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41DF Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41E0 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41E1 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41E4 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41E6 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41E7 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41E8 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41E9 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41EA Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41EB Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41ED Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41EE Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41EF Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F0 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F1 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F2 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F4 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F5 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F6 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F7 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F8 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41F9 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41FB Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41FC Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
41FD Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4202 Undervoltage supply
4203 Undervoltage supply
4215 Voltage pulse
4216 Voltage pulse
4221 Overvoltage supply
4222 Overvoltage supply
4223 Undervoltage supply
4224 Undervoltage supply
4301 L6/1 (left front speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
432E L6/1 (left front speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
432F Check component L6/1 (left front speed sensor).
4336 Check component L6/1 (left front speed sensor).
4337 Check component L6/1 (left front speed sensor).
4338 This fault can be ignored and erased.
433A Check component L6/1 (left front speed sensor).
433C Check component L6/1 (left front speed sensor).
43AC Check component L6/1 (left front speed sensor).

43AE	Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and A7/3n1 (SBC control unit)
43AF	Check component L6/1 (left front speed sensor).
4401	L6/2 (right front speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
442E	L6/2 (right front speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
442F	Check component L6/2 (right front speed sensor).
4436	Check component L6/2 (right front speed sensor).
4437	Check component L6/2 (right front speed sensor).
4438	This fault can be ignored and erased.
443A	Check component L6/2 (right front speed sensor).
443C	Check component L6/2 (right front speed sensor).
44AC	Check component L6/2 (right front speed sensor).
44AE	Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and A7/3n1 (SBC control unit)
44AF	Check component L6/2 (right front speed sensor).
4501	L6/3 (left rear speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
452E	L6/3 (left rear speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
452F	Check component L6/3 (left rear speed sensor).
4536	Check component L6/3 (left rear speed sensor).
4537	Check component L6/3 (left rear speed sensor).
4538	This fault can be ignored and erased.
453A	Check component L6/3 (left rear speed sensor).
453C	Check component L6/3 (left rear speed sensor).
45AC	Check component L6/3 (left rear speed sensor).
45AE	Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and A7/3n1 (SBC control unit)
45AF	Check component L6/3 (left rear speed sensor).
4601	L6/4 (right rear speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
462E	L6/4 (right rear speed sensor) : Speed signal from control module A7/3n1 (SBC control unit) implausible
462F	Check component L6/4 (right rear speed sensor).
4636	Check component L6/4 (right rear speed sensor).
4637	Check component L6/4 (right rear speed sensor).
4638	This fault can be ignored and erased.
463A	Check component L6/4 (right rear speed sensor).
463C	Check component L6/4 (right rear speed sensor).
46AC	Check component L6/4 (right rear speed sensor).
46AE	Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and A7/3n1 (SBC control unit)
46AF	Check component L6/4 (right rear speed sensor).
4711	Inspect rpm sensor.
4721	Inspect rpm sensor.
4742	One or more speed sensors have implausible values.
4746	One or more speed sensors have implausible values.

4750	One or more speed sensors have implausible values.
4820	Inspect component Rpm sensor for correct installation position.
4821	L6/1 (left front speed sensor) : The rotation direction is incorrect.
4822	L6/2 (right front speed sensor) : The rotation direction is incorrect.
4823	L6/3 (left rear speed sensor) : The rotation direction is incorrect.
4824	L6/4 (right rear speed sensor) : The rotation direction is incorrect.
4840	Inspect rpm sensor.
490E	Fault or defect in CAN communication.
490F	Fault or defect in CAN communication.
4931	Fault or defect in CAN communication.
4932	Fault or defect in CAN communication.
4940	Test CAN connection to A7/3n1 (SBC control unit).
4941	Test CAN connection to A7/3n1 (SBC control unit).
49C0	Test CAN connection to A7/3n1 (SBC control unit).
4A10	Engine control module not identified or incorrect control module
4A20	Engine control module not identified or incorrect control module
4A30	Engine control module not identified or incorrect control module
4A40	Engine control module not identified or incorrect control module
4A41	The control module does not match the vehicle model.
4A42	Fault in CAN communication with control unit CGW.
4A50	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4A60	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4AB0	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
4AC0	Engine control module not identified or incorrect control module
4B40	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4B41	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4B42	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4B44	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4B45	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4B46	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4B47	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4B49	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4BA0	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4BA2	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C01	This fault can be ignored and erased.
4C02	This fault can be ignored and erased.
4C03	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C04	The supply voltage of component B24/15 (Rotary speed and lateral acceleration sensor) is too high (overvoltage).
4C05	The supply voltage of component B24/15 (Rotary speed and lateral acceleration sensor) is too low (undervoltage).
4C06	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4C07	The supply voltage of component B24/15 (Rotary speed and lateral acceleration sensor) is too low (undervoltage).
4C10	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4C12	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4C14	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C16	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.

4C18 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C1A Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C1E Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C22 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C26 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C28 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C2C Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C30 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C31 Check component B24/15 (Rotary speed and lateral acceleration sensor).
4C32 Check component B24/15 (Rotary speed and lateral acceleration sensor).
4C34 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C38 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C3A Check component B24/15 (Rotary speed and lateral acceleration sensor).
4C3C Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4C3F Check component B24/15 (Rotary speed and lateral acceleration sensor).
4C50 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C52 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C53 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C54 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C55 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C56 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C57 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C58 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C59 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C5A Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C5B Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4C5C Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CAA Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CAC Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CAD Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4CAE Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4CAF Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4CB0 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4CB1 Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
4CB5 Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CB7 Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).

4CB8	Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CB9	Check component B24/15 (Rotary speed and lateral acceleration sensor). (Incorrect sensor type)
4CBA	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CBB	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CBC	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CBD	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CBE	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CBF	Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CC0	Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CC2	Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CC3	Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CC4	Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CC6	Fault in CAN communication with component B24/15 (Rotary speed and lateral acceleration sensor).
4CC7	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CC8	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CC9	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CCA	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CCB	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CCC	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CCD	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CCE	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CCF	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CD0	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CD1	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CD2	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CD3	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CD4	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CD5	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CD6	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CF0	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CF1	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CF2	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4CF3	Check component B24/15 (Rotary speed and lateral acceleration sensor).
4D01	This fault can be ignored and erased.
4D02	This fault can be ignored and erased.
4D2E	Check component N49 (Steering angle sensor).
4D30	Check component N49 (Steering angle sensor).
4D34	Check component N49 (Steering angle sensor).
4D36	Check component N49 (Steering angle sensor).
4D38	Check component N49 (Steering angle sensor).
4D3C	Check component N49 (Steering angle sensor).

4D3D Check component N49 (Steering angle sensor).
4D3E Check component N49 (Steering angle sensor).
4D40 Check component N49 (Steering angle sensor).
4D41 Check component N49 (Steering angle sensor).
4D42 Check component N49 (Steering angle sensor).
4E01 System faults : Control implausible
4E02 System faults : Control implausible
4F01 This fault can be ignored and erased.
5044 Road test : Pressure sensor , Signal fault
5045 Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Lateral acceleration sensor)
5048 Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Yaw rate sensor)
5049 Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Yaw rate sensor)
504A Road test : Steering wheel angle sensor
504B Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Lateral acceleration sensor)
5055 Road test : B24/15 (Rotary speed and lateral acceleration sensor)
5056 Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Lateral acceleration sensor)
5057 Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Yaw rate sensor)
505A Engine control module not identified or incorrect control module
505B Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Yaw rate sensor)
505C Road test : B24/15 (Rotary speed and lateral acceleration sensor) , Signal fault (Lateral acceleration sensor)
5150 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5160 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5201 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5523 Fault in CAN communication with control unit A7/3n1 (SBC control unit).
5524 Fault in CAN communication with control unit A7/3n1 (SBC control unit).
5531 CAN communication to control module A7/3n1 (SBC control unit) is faulty.
5532 CAN communication to control module A7/3n1 (SBC control unit) is faulty.
5551 CAN communication to control module A7/3n1 (SBC control unit) is faulty.
5610 System faults : Check control unit A7/3n1 (SBC control unit).
5611 System faults : Check control unit A7/3n1 (SBC control unit).
5801 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5802 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5803 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5804 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5805 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5806 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5807 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5808 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5809 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
580A Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
580B Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.

580C Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
580D Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
580E Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
580F Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5810 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5811 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
58A0 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
58A1 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5930 Fault in CAN communication with control unit ABC active body control.
5A01 Check component Y10 (SPS solenoid valve).
5A03 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
5A06 Check component Y10 (SPS solenoid valve).
5A07 Check component Y10 (SPS solenoid valve).
5B0A Check control unit Engine management.
5B0B Check control unit N80 (Steering column module).
5B15 Check control unit N47-5 (ESP, SPS [PML] and BAS control unit).
5B16 Check control unit N47-5 (ESP, SPS [PML] and BAS control unit).
5E01 Tire pressure loss warner : Internal fault
5E02 Tire pressure loss warner : Internal fault
5E03 Tire pressure loss warner : Internal fault
6101 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6102 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6103 Fault or defect in CAN communication.
6104 Fault or defect in CAN communication.
620F Fault in control unit A7/3n1 (SBC control unit): Short-time cutout during operation
6250 Fault in control unit A7/3n1 (SBC control unit): Short-time cutout during operation
6251 Fault in control unit A7/3n1 (SBC control unit): Short-time cutout during operation
6261 Check ground connections of component A7/3n1 (SBC control unit).
6401 Undervoltage supply
6402 Undervoltage supply
6403 Undervoltage supply
6404 Fault in control unit A7/3n1 (SBC control unit): Short-time cutout during operation
6502 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6503 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6610 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
671F Line between control unit N47-5 (ESP, SPS [PML] and BAS control unit) and component Y113/1 (Simulator shutoff valve) has short circuit to positive.
6720 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6721 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6722 Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6780 Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and Y113/1 (Simulator shutoff valve)
6781 Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and Y113/1 (Simulator shutoff valve)
6782 Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and Y113/1 (Simulator shutoff valve)
6783 Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and Y113/1 (Simulator shutoff valve)

67B0	Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and Y113/1 (Simulator shutoff valve)
67B1	Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and Y113/1 (Simulator shutoff valve)
67C0	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
67C1	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6810	Check lines between N47-5 (ESP, SPS [PML] and BAS control unit) and Y113/1 (Simulator shutoff valve)
6811	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
68B8	Control unit N47-5 (ESP, SPS [PML] and BAS control unit) is defective.
6B21	Fault in function 'Hill Start Assist'
6B40	Fault in function 'Hill Start Assist'
6C60	Component B24/15 (Rotary speed and lateral acceleration sensor) is not learned.
6C61	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
6C62	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
6C63	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
6C64	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
6C70	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
6C90	Component B24/15 (Rotary speed and lateral acceleration sensor) is defective.
7202	DTR : Test wheel speed signals. (Front axle)
7203	DTR : Test wheel speed signals. (Rear axle)
7204	DTR : Test wheel speed signals.
7205	DTR : The CAN message from control module A7/3n1 (SBC control unit) is invalid or implausible. (Brake request of driver)
720A	DTR : Check control unit A89 (DTR controller unit) for faults.
720D	DTR : This fault can be ignored and erased.
7304	DTR : Check component A89 (DTR controller unit).
7305	DTR : Check component A89 (DTR controller unit).
Event 4101	Programming of control module successfully completed.
Event 4201	Increase of idling set speed
Event 490C	Fault or defect in CAN communication.
Event 490D	Fault or defect in CAN communication.
Event 4910	Fault or defect in CAN communication.
Event 4A43	Check codings in control module CGW. (Model year)
Event 4D32	Fault in CAN communication with control unit N80 (Steering column module).
Event 4D43	Fault in CAN communication with control unit N80 (Steering column module).
Event 4D50	Fault in CAN communication with control unit N80 (Steering column module).
Event 4D51	Fault in CAN communication with control unit N80 (Steering column module).
Event 5041	Road test : ACTIVE
Event 5050	Road test : Driving test successfully completed
Event 5314	The CAN message from control module Motor electronics is invalid or implausible. (Accelerator pedal position)
Event 5315	The CAN message from control module Motor electronics is invalid or implausible.
Event 5316	The CAN message from control module Motor electronics is invalid or implausible. (Engine speed)
Event 5317	The CAN message from control module Motor electronics is invalid or implausible. (Maximum engine torque)

Event 5318	The CAN message from control module Motor electronics is invalid or implausible. (Engine torque)
Event 5319	The CAN message from control module Motor electronics is invalid or implausible. (Minimum engine torque)
Event 531A	The CAN message from control module Motor electronics is invalid or implausible.
Event 5350	The CAN communication of the engine control module is faulty.
Event 5351	The CAN communication of the engine control module is faulty.
Event 5352	The CAN communication of the engine control module is faulty.
Event 5353	The CAN communication of the engine control module is faulty.
Event 5354	The CAN communication of the engine control module is faulty.
Event 5355	The CAN communication of the engine control module is faulty.
Event 5356	The CAN communication of the engine control module is faulty.
Event 5357	The CAN communication of the engine control module is faulty.
Event 5358	The CAN communication of the engine control module is faulty.
Event 5359	The CAN communication of the engine control module is faulty.
Event 53F0	CAN communication with control unit Engine management is sporadically disturbed.
Event 53F1	The CAN communication of the engine control module is faulty.
Event 5450	CAN communication with transmission control unit is faulty.
Event 5451	CAN communication with transmission control unit is faulty.
Event 54EE	CAN communication with transmission control unit is faulty.
Event 54EF	CAN communication with transmission control unit is faulty.
Event 54F0	CAN communication with control unit Transmission control is sporadically disturbed.
Event 54F1	CAN communication with control unit Transmission control is sporadically disturbed.
Event 5501	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5502	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5503	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5504	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5505	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5506	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5507	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5508	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5509	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 550A	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 550B	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 550C	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 550D	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 550E	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5520	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5521	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5522	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5550	Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 5750	Roller dynamometer mode is activated.
Event 5901	Fault in CAN communication with control unit N51/2 (ABC control module).
Event 5950	Fault in CAN communication with control unit N51/2 (ABC control module).
Event 5951	Fault in CAN communication with control unit N51/2 (ABC control module).

Event 5A02	Check codings in control module CGW. (National version)
Event 5B02	CAN communication with transmission control unit is faulty.
Event 5B03	The CAN message from control module N93 (Central gateway control unit) is invalid or implausible.
Event 5B04	CAN communication to control module A1 (Instrument cluster) is faulty.
Event 5B05	The CAN communication of the engine control module is faulty.
Event 5B06	The CAN communication of the engine control module is faulty.
Event 5B07	CAN communication to control module CGW is faulty.
Event 5B08	The CAN communication of the engine control module is faulty.
Event 5B09	CAN communication to control module CGW is faulty.
Event 5B0C	Check control unit N10/1 (Driver-side SAM control unit with fuse and relay module).
Event 5B0D	Temperature monitor
Event 5B0E	Check control unit N10/1 (Driver-side SAM control unit with fuse and relay module).
Event 5B0F	Check control unit A7/3n1 (SBC control unit).
Event 5B10	Check control unit N15/5 (Electronic selector lever module control unit).
Event 5B12	Check control unit N10/1 (Driver-side SAM control unit with fuse and relay module).
Event 5B13	Check control unit N82 (Battery control module).
Event 5B14	Check control unit A1 (Instrument cluster).
Event 5B17	CAN communication to control module CGW is faulty.
Event 5C05	CAN communication to control module CGW is faulty.
Event 5C06	CAN communication to control module CGW is faulty.
Event 5C07	CAN communication to control module CGW is faulty.
Event 5C08	Fault or defect in CAN communication.
Event 5C0A	Fault in CAN communication with control unit N93 (Central gateway control unit).
Event 5C10	Fault in CAN communication with control unit A1 (Instrument cluster).
Event 5C11	Fault or defect in CAN communication.
Event 5C12	Fault in CAN communication with control unit A1 (Instrument cluster).
Event 5C13	Fault in CAN communication with control unit A1 (Instrument cluster).
Event 5C14	Fault in CAN communication with control unit Air suspension.
Event 5C15	Fault in CAN communication with control unit Air suspension.
Event 5C16	Fault in CAN communication with control unit A1 (Instrument cluster).
Event 5C17	Fault in CAN communication with control unit A1 (Instrument cluster).
Event 5C18	Fault in CAN communication with control unit N93 (Central gateway control unit).
Event 5C19	Fault in CAN communication with control unit N93 (Central gateway control unit).
Event 5C1A	Fault in CAN communication with control unit N73 (EIS [EZS] control unit).
Event 5C1B	Fault in CAN communication with control unit N73 (EIS [EZS] control unit).
Event 5D02	Component N49 (Steering angle sensor) is not initialized.
Event 6202	Ignore event code and erase event memory.
Event 7201	DTR : The CAN communication of the engine control module is faulty.
Event 7206	DTR : CAN communication with transmission control unit is faulty.
Event 7207	DTR : CAN communication with transmission control unit is faulty.
Event 7208	DTR : Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 7209	DTR : CAN communication with transmission control unit is faulty.
Event 720C	DTR : Fault in CAN communication with control unit A7/3n1 (SBC control unit).
Event 720F	DTR : The CAN communication of the engine control module is faulty.

Event 7210	DTR : The CAN communication of the engine control module is faulty.
Event 7211	DTR : The CAN communication of the engine control module is faulty.
Event 7212	DTR : The CAN communication of the engine control module is faulty.
Event 7213	DTR : The CAN message from control module EZS is invalid or implausible.
Event 7214	DTR : The CAN communication of the engine control module is faulty.
Event 7220	DTR : The CAN communication of the engine control module is faulty.
Event 7221	DTR : Component N49 (Steering angle sensor) is not initialized.
Event 7222	DTR : The CAN message from control module N80 (Steering column module) is invalid or implausible.
Event 7223	DTR : The CAN message from control module N80 (Steering column module) is invalid or implausible. (Cruise control lever)
Event 7224	DTR : Fault in CAN communication with control unit N80 (Steering column module).
Event 7230	DTR : CAN communication to control module N80 (Steering column module) is faulty.
Event 7240	DTR : CAN communication with transmission control unit is faulty.
Event 7242	DTR : The CAN communication of the engine control module is faulty.
Event 7244	DTR : The CAN communication of the engine control module is faulty. (Warning signal)
Event 7246	DTR : CAN communication to control module EZS is faulty.
Event 7247	DTR : The CAN communication of the engine control module is faulty.
Event 7248	DTR : CAN communication to control module N80 (Steering column module) is faulty.
Event 7250	DTR : The CAN bus message of component N80 (Steering column module) is implausible. (Cruise control lever)
Event 7251	DTR : Check codings in control module N93 (Central gateway control unit).
Event 7252	DTR : The CAN communication of the engine control module is faulty.
Event 7253	DTR : Check codings in control module Engine management.
Event 7254	DTR : CAN communication with control unit Engine management is sporadically disturbed.
Event 7255	DTR : CAN communication with control unit Engine management is sporadically disturbed.
Event 7256	DTR : CAN communication with control unit N73 (EIS [EZS] control unit) is sporadically disturbed.
Event 7258	DTR : CAN communication with control unit N15/3 (ETC [EGS] control unit) is sporadically disturbed.
Event 7267	DTR : CAN communication with control unit A1 (Instrument cluster) is sporadically disturbed.
Event 7268	DTR : CAN communication with control unit N80 (Steering column module) is sporadically disturbed.
Event 7270	DTR : CAN communication with control unit Engine management is sporadically disturbed.
Event 7271	DTR : CAN communication with control unit Engine management is sporadically disturbed.
Event 7273	DTR : CAN communication with control unit N93 (Central gateway control unit) is sporadically disturbed.
Event 7275	DTR : CAN communication with control unit Engine management is sporadically disturbed.
Event 7276	DTR : CAN communication with control unit N93 (Central gateway control unit) is sporadically disturbed.

Event 7301	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7302	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7303	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7306	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7307	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7308	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7309	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7310	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7311	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7312	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7313	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7314	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7315	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7316	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7321	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7322	DTR : Fault in CAN communication with component A89 (DTR controller unit).
Event 7323	DTR : Fault in CAN communication with component A89 (DTR controller unit).

Filename: F:\Programme\Das\trees\PKW\TRAKTION\sbc121f\menues\mnsbc121f.s

Cell co-ordinate: 7 , 22