
MODEL 209 except CODE (581b) Convenience automatic air conditioning



P83.10-2267-09

- 1 Bolts
- Cross member below instrument panel
- 3 Electrical connector

M2/15 Left and right footwell flaps actuator motor

Modification notes

18.2.04	Disconnect/connect/remove ground lead from battery	

XX	Remove/Install		
1	Remove cross member under instrument panel (2)	Model 209.3	AR68.10-P-1120Q
		Model 209.4	AR68.10-P-1120QA
2	Remove damping in the area of the left and right footwell flaps actuator motor (M2/15)		
3	Remove bolts (1)		
4	Detach left and right footwell flap actuator motor (M2/15)		
5	Separate electrical connection (3)		
6	Install in the reverse order		
7 ► A D	Connect STAR DIAGNOSIS, normalize left and right footwell flaps actuator motor (M2/15), read out and erase fault memory Connect STAR DIAGNOSIS and read out		AD00.00-P-2000-04A
	fault memory	Diagnosis system STAR DIAGNOSIS	*WH58.30-Z-1048-13A
8	Perform function check	Blagnosis system STATT BINGNOSIS	111100.00 Z 1040 10A

Commercially available tools

Number Designation		
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car	6511 1801 00